Action: Previous page

If you assign the action *Previous page* to a button, the system switches to the last opened page.

IMPORTANT: The page history is only saved as long as the APP is open. When the app is closed, the history is deleted. After a restart of the app this function is not available.