

MANUAL IQONTROL NEO

Contents

- [First Steps: About IQONTROL NEO & Account](#)
 - [How to integrate the AIO GATEWAY into IQONTROL NEO](#)
 - [The User Interface: IQONTROL NEO dashboard](#)
 - [The Main Menu](#)
- [Add rooms and devices](#)
 - [Integrate IP-cameras](#)
 - [Add Cloud Devices](#)
 - [Integrate IP devices and IP gateways](#)
 - [Add IR-Devices](#)
 - [Direct links between devices](#)
 - [End position settings and travel times for shutters or blinds](#)
- [Create scenes](#)
- [Create tasks](#)
 - [Push messages](#)
 - [Use Open Weathermap](#)
 - [Alarm tasks](#)
 - [Set hysteresis value in tasks](#)
 - [calendar: overview of time-scheduled tasks](#)
- [Alarm](#)
 - [Device restrictions](#)
 - [Switch to the new alarm](#)
 - [Absence & presence mode](#)
 - [Alarm configuration](#)
 - [Activation delay](#)
 - [Sound confirmation](#)
 - [Alarm keys](#)
 - [Front door](#)
 - [PIN](#)
 - [Messages](#)
 - [Alarm status](#)
 - [Cloud activation](#)
 - [Activate/ Deactivate alarm](#)
 - [Reset alarm](#)
 - [Alarm - example of use](#)
- [Lock gateway](#)
- [QR Code archive](#)
- [Heating schedules](#)
- [Gateway settings](#)
- [Z-Wave and EnOcean: Activate extensions for V6 Plus or V5 Plus](#)
- [Save & load configurations](#)
 - [Save restricted configuration](#)
- [Remote mode](#)
- [Voice control & more: Upload to the mediola cloud](#)
- [FAQ](#)
- [Changelog](#)

From:

<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:

http://doku.mediola.com/doku.php?id=en:iqontrol_neo:start

Last update: **2020/10/12 15:08**

