

Integrate Philips hue bridge as a gateway

If you are using the AIO CREATOR NEO with a Philips hue plug-in, you can integrate the hue bridge as a gateway in the device manager. For this purpose you can use the „search gateway“ button, to import the configuration of your hue bridge automatically. Alternatively you can configure your hue bridge manually by clicking the „new gateway“ button.

Important note: The Philips hue bridge can only be found and imported automatically, if it is in the same subnet as the computer, on which the AIO CREATOR NEO software is used.

If your hue bridge has not been found automatically, you can configure it manually. In this case please click the „new gateway“ button. Now enter a name, select the type (Philips hue) and enter IP-address, Port-Number, User and - if necessary - User and Password.

From:

<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:

<http://doku.mediola.com/doku.php?id=en:creator:ui-menu-devicemanager-hueimport>

Last update: **2016/01/27 14:22**

