## Integrate the netatmo central unit as a gateway

If you are using the AIO CREATOR NEO with a netatmo plug-in, you can integrate netatmo as a gateway in the device manager.

Important: Since NEO does not connect the netatmo central unit directly via local network, but via your netatmo cloud server account, an Internet connection is required.

To create a netatmo gateway please open the gateways tab of the device manager and click the „new gateway" button. Now enter a name, select "netatmo (Online)" in the "Type"-dropdown and enter Username and Password of your netatmo cloud server account.

Finally store the netatmo gateway by clicking on "Save".