


Delete remotes on the cloud-server

If you want to remove a remote from the cloud-server, go to the “settings menu”, select “remote” and then “download”.

Once you have authenticated, you can delete a remote by clicking the -icon.



Note: This action only deletes the copy of the remote file on the server, not the local remote file.

From:
<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:
<http://doku.mediola.com/doku.php?id=en:creator:ui-menu-remotes-delete>

Last update: **2015/11/26 14:39**

