

General


The remote mode allows IQONTROL users to control their gateway from outside their network. Please note that while using the remote mode the display of status indications could be delayed approx. one to two minutes.

Note: You can only control devices via remote mode which are controlled by the AIO Gateway. IP-devices like Sonos or Philips Hue are controlled directly via IQONTROL-App and not via the gateway. Due to this fact they can't be controlled with the remote mode.

Activate the remote mode

Before you can use the remote mode you have to activate it for every gateway. To activate the remote mode you have to open the category "Settings" and then the tab "Settings". Now select the gateway for which you want to activate the remote mode.

Now you have to check the checkbox "Enable Remote Access".



Switch between local and remote

To control your gateway from the outside you have to tap on the remote mode symbol on the startpage. (One tap activate, two taps deactivate).

Local (remotemode off):



Remote (remotemode on):



From:

<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:

<http://doku.mediola.com/doku.php?id=en:iqontrol:remotemode>

Last update: **2016/06/27 17:51**

