

Introduction

If you want to use your AIO GATEWAY V5 in combination with AIO CREATOR NEO, it is necessary to configure the gateway and connect it to your network. For this purpose you have to use the ConfigTool NEO.

To download the current Version of the ConfigTool NEO go to this [Link](#). Please install the program and launch it afterwards.

Note: You can't setup and configure AIO GATEWAYS Version 4 and below via ConfigTool NEO. For this gateway versions the ConfigTool is required.

From:

<https://doku.mediola.com/> - **Dokumentationen**

Permanent link:

<https://doku.mediola.com/doku.php?id=en:v5:introduction>

Last update: **2016/06/24 14:07**

