

Reset gateway

To reset your gateway you have to push and hold the reset button on the back of the gateway and release the button in one of the following reset-modes:

LED lights **green**: reset WLAN/WiFi settings.

LED lights **orange**: reset WLAN/WiFi settings and the user-password.

LED lights **red**: reset to factory settings.

Important: Release the reset button when the LED has the color of the reset mode, to execute this reset mode.

From:

<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:

<http://doku.mediola.com/doku.php?id=en:v6:reset>

Last update: **2019/08/27 15:05**

