



firmware update

To update the firmware of the AIO GATEWAY V6, select the *General* tab in the ConfigTool NEO. If a firmware update is available, a notification appears in the ConfigTool NEO.



Click on “Install update” to start the update.



After the update has started, a process bar will show the process of the update. Once it has reached 100% and the update is completed, the AIO GATEWAY V6 restarts and you will automatically return to the overview.

Manual firmware update

You can also manually install firmware, for example to fix a problem with the gateway. This is only possible if your gateway is set to [recovery mode](#).

From:

<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:

<http://doku.mediola.com/doku.php?id=en:v6:v6plus-firmwareupdate>

Last update: **2020/06/24 17:33**

