FAQ

User directory: Where is it?

The user directory with the stored gateways, devices, macros and your remote files is located here:

- Win XP: `\Documents and Settings\$USER$\My Documents\AIO CREATOR NEO`
- Win Vista/7/8: `\Users\$USER$\Documents\AIO CREATOR NEO`
- Mac OSX: `/Users/$USER$/Documents/AIO CREATOR NEO`
- others: `~/AIO CREATOR NEO`

Log-file: Where is it?

The log file is in the user directory in the subfolder 'logs'.

From:
http://doku.mediola.com/ - **Dokumentationen**

Permanent link:
http://doku.mediola.com/doku.php?id=en:creator:faq

Last update: **2016/01/14 12:52**