


Cloud activation

By default, activation / deactivation is not possible via the cloud for security reasons. The user must set this manually. To do this, go to Settings → Alarm. Tap Cloud Activation. Check the box next to “Cloud activation”. Now the alarm can also be activated / deactivated via the Internet.



From:
<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:
http://doku.mediola.com/doku.php?id=en:iqontrol_neo:alarm_cloudaktivierung

Last update: **2020/07/21 15:40**

