


Background of remote pages and global settings

If the background of a remote page is selected, you have the following setting options in the properties menu.

Size: A remote and the included pages should fit to the display resolution (width x height) of the used mobile unit. You can edit the size of each page manually.

Background color: Any remote page has a defined background color which will be visible, if no or a too small background image has been selected. To define the color you can use the colorchooser or insert a hexadecimal color code manually.



Background image: You can select a background image by clicking on the edit-icon (pencil). You can use one of the standard images from the image catalog or import any individual image (supported formats: PNG & JPG). Please consider, that it is helpful, that the background image has the same size as the remote page. Although there are some scaling options you should pay attention to the fact, that if you don't keep the aspect ratio, the image will be distorted. Please note also: If the image is too big, it will be cut off and if it is too small the missing part will be filled with the background color.

Define swipe gestures: You can define the four one-finger-swipes „up“, „down“, „left“ and „right“ individually for any remote page.

The following options are available for swipes:

- execute command
- execute macro

- switch page
- refresh page
- control camera
- send HTTP request
- no action

Important Note:

Two-finger-swipes are system commands and can not be changed. Function of two-finger-swipes:

- up→ open setup
- left→ move to previous page
- right→ move to the following page

Page status and page action: Similar to buttons, a page can also be assigned a status and a status value. In addition, an action can be defined that is carried out when the page status occurs. E.g. changing to a certain page when the doorbell rings. → [More details about page status and page status action](#)

Auto-Refresh: You can enable/ disable the auto-refresh for every remote page and define the refresh-time.

Set password: Choose a password to protect the remote page.

Click Sound / Vibration: Option to set the occurrence of a click sound or vibration on tapping a button element.

From:
<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:
<http://doku.mediola.com/doku.php?id=en:creator:ui-remote-pages-background>

Last update: **2020/03/09 17:15**

